TC 30 REMOTE CONTROL FUNCTIONS
(PREPROGRAMMED TO OPERATE THE AVR 745)

1. USB Connector
2. IR Emitter Window
3. Power Button
4. Activities Button
5. Devices Button
6. Help Button
7. Screen Buttons
8. LCD Screen
9. Page Left/Right Buttons
10. Transport Control Buttons
11. Device Control Buttons
12. Mute Button
13. Volume Controls
14. Navigation Buttons
15. OK/Enter Button
16. Glow Button
17. Channel Up/Down
18. Numeric Keys
19. Infrared Learning Port

